

How to check your bull probe for resistance.

- 1) You will need a voltage meter.
- 2) Make sure electrodes are cleaned to a shiny silver using the scotch brite pad provided with your probe.
- 3) Set your voltage meter to “ohms” on the lowest setting.
- 4) If you have an alligator clip, clip it to one of the outside pins of the connector, take the other end and put on one electrode one at a time.
- 5) Repeat this with the other outside pin. Readings should be under 1 ohm. Also touch to the “tailstock” to make sure there isn’t a short. The two outside electrodes will be hooked to one of outside pins and the center will be hooked to the other. The third pin is not hooked to anything.

Any questions or concerns please call, 800-777-2603 or email us, lanemfg@gmail.com