Replacing the Batteries in your Lane Ram Ejaculator



Replacing the batteries in your Lane Ram Ejaculator may appear to be a daunting task, but it is one of the simplest fixes you can do and only takes a matter of minutes. By following these simple steps, you will be able to quickly and correctly replace the batteries in your machine and get you back to work in no time!

What you will need:

- A Phillip's head Screwdriver
- Two (2) 9 Volt Batteries

<u>Step One:</u> The most important step when working with this product is to keep it on a flat and stable surface at all times. Failing to do this could result in snapped wires or damage to your unit.

<u>Step Two:</u> Using your Phillip's head screwdriver, remove the four (4) screws from the case and set them to one side. Once you have removed all of the screws, gently lift the lid off the case and fold it back towards the button (as seen below).



<u>NOTE:</u> Be cautious while performing this step! DO NOT yank the lid off, or leave the lid dangling. This could damage the wires and other components to your Ram Ejac, thus resulting in you shipping your unit to us. If the lid does not come off easily, gently pry it off with a flat head screwdriver, again, while being careful not to damage any components on the inside.

<u>Step Three:</u> Remove one battery at a time by gently lifting from the bottom end of the battery out of the battery clip (seen below).



<u>Step Four:</u> Once each battery has been removed from the clips, unsnap the top cover from the battery and dispose of the batteries properly.

<u>Step Five</u>: Replace each battery with a new 9 Volt Battery by securing each with the snap connectors and slide them back into the battery clips with the top of the battery facing towards the button side.

<u>Step Six:</u> Before placing the lid back on top, be sure that there are no wires hanging over the edge. If so, gently and without pulling, move the wires into the case and carefully place the lid on top. Once again, make sure that the unit is placed on a flat, solid surface and screw in each of the four screws until snug.

If you are still having issues with your unit after taking these steps, do not hesitate to call us and we will do our best to solve the issues over the phone first before requesting you to send in your Ram Ejaculator.

For further inquiries, please contact Bob or Leigh Green at: Lane Manufacturing, Inc. 2045 South Valentia Street Unit 11 Denver, Colorado 80231 Phone: (800) 777-2603 E-Mail: lanemfg@earthlink.net